



netfabb for fabbster

Installation and Activation

Copyright by netfabb GmbH 2010

support@netfabb.com

Version: May 7, 2012

This document shall not be distributed without the permission of netfabb GmbH.

Chapter 1


Installation of netfabb

To get the netfabb Engine for fabbster running on your system, go to wiki.fabbster.com -> **netfabb Engine for fabbster** -> **Installation**. Please choose between the online and the offline installer. The first one needs constant internet connection and will look for netfabb updates during the later use of the software. For a computer without internet connection, choose the offline installer and check our website for updates from time to time. Please also have your serial number and voucher code ready. You can find them on the electronic box of your fabbster.

The installation file starts an installation dialog box, where you first have to select the installation language, and you can check a box to look online for updates. This documentation is a guide for the English installation. The language of the software itself can be changed later on in the settings. When you are finished, click "Continue".



If you look automatically for updates, fill in specifications of your internet connection in the next step. If a direct internet connection is detected, you can simply click on "Continue". In the next window, please read the terms and conditions of the use of the netfabb Engine. You have to tick the box "Accept" in the bottom left in order to continue.



Then, you can enter your settings. You can install netfabb only for the current user or for all users on your computer; In any case, you must have the writing authorization for the installation directory. Next, enter an installation directory and choose whether you want to create a startmenu entry and/or link STL files automatically to netfabb.



When you click "Continue", the software is installed.



The installation is now complete. In the last window, a box is checked to start the software directly.



Chapter 2

Activation

After installing, it is necessary to activate the Engine. If you have acquired the netfabb Engine for fabbster Professional, the software is activated with your dongle license. In that case, please check the PDF-documentation "Installation and Activation" on your disc on how to proceed. With the netfabb Engine for fabbster Basic, you have to activate the software with your serial number and voucher code as soon as you start the software for the first time. First, select which version of the software you have. With a serial number, click on "Full Version".



If you have acquired the full version, you will be asked to insert your name, company or institution, email address and the serial number and voucher number, which can be found on the electronic box of your fabbster. Insert this information and click on "Activate Online".

netfabb product activation

Get unlock code for full version

Please enter your registration data and voucher code:

Name:	<input type="text"/>
Company/Institution:	<input type="text" value="netfabb GmbH"/>
Email:	<input type="text" value="info@netfabb.com"/>
Serial number:	<input type="text" value="12345678"/>
Voucher code:	<input type="text" value="xyzxyz"/>

After entering your data, click "Activate online". If your computer has no internet connection, you can commit the necessary data by web form from a different computer. To do so, please click "Activate offline".

After entering your data, your version is activated and you are free to use netfabb Studio Basic for fabbster.

netfabb product activation

Activation successfully completed


Thank you for activating netfabb. Have fun!

If you do not have an internet connection on your computer, you will have to activate offline. After clicking on this button, you will get your information again and will be able to save them as txt-file. Copy this file and go to <http://www.netfabb.com/netfabbactivation.php> on a computer with internet connection. There, copy your information in the respective fields and click on "Send". An email will then be sent to the address you entered, containing the Unlock code. Enter this code into the remaining field in the netfabb activation dialog. This activates your netfabb Engine for fabbster.


Chapter 3

Getting the fabbster running


The last step in preparing your computer for working with the fabbster, is the installation of the driver. It can be downloaded on wiki.fabbster.com -> **firmware** -> **install device driver for fabbster 3D printer**. Switch on your fabbster and stick the USB cable to the USB port on your computer. Please be careful to always use the same port, since the computer will remember which one you used and ask for another driver installation if you use another port. Then click on the windows start button, search for the "Device Manager" in the input field and choose the "Device Manager".




In the folder "Other devices" appears the "Sintermask Fabbster". Right-click on it and choose "Update Driver Software".




Then, Windows asks you how you want to search for the driver software. Click on "Browse my computer for driver software".




Now choose the folder with the fabbster driver and click on "Next". Mind to only choose the folder where the executable file was saved, not the file itself.



Next, a window will appear which says, that "Windows can't verify the publisher of this driver software". This is just precaution, netfabb won't harm your computer, of course. So just click on "Install this driver software anyway."



The installation progresses and is being finished.



Your computer is now ready to work with the fabbster.
